

Digital Imaging and Audio Lab (DIAL) INSTRUCTIONS

Video2Digital 3.0 VHS/DVD/Camcorder Converter

Royal Oak Public Library Makerspace

1. Make sure the video player is connected properly to the Video2Digital box. It should be showing the blue screen in the recording window.
2. Make sure that a Flash Drive is in the Video2Digital device otherwise the device will not record any of your material; be it DVD, CD, VHS, and/or Camcorder tape into digital format.
3. Press “Menu” then scroll down and select “Record Audio or Video” then press “OK”. Make sure it on press “Audio+Video” and then press “OK.” Press “Menu” to exit.
4. Make sure the white, red, and yellow are in the right locations.
5. Press Play on the video player and then immediately press Record on the Video2Digital software to start recording.
6. Things must be played in real time to be recorded, so depending on the length of the tape, it could take some time.
7. When the tape is finished, press the Stop button on both the video player and the Video2Digital.
8. Files will be saved to the Flash Drive/Memory Card.



Record Button Start and Stop